

## AXSTEC Steps

## Front Entry



The **AXSTEC** Front Entry is a double step entry for the right front door.

This low front step is specially made for Mercedes-Benz Sprinter and Volkswagen Crafter. The step is mounted within the original chassis of the vehicle, placed at the right front door. The step gives you easy access to the vehicle and provides you more space inside for different seat lay-out.

### AXSTEC Front Entry Features:

- Relative fast mounting
- No welding at the vehicle.
- No painting at the vehicle
- Easy replacement from the extended door panel
- Light weigh (ads only 3 kg)t
- Same appearance as original step area.



### AXSTEC fixed step Specifications:

Step entry / door extender

Material: PE (POLYETHYLENE)

Step nosing with Fluorescent non-slip safety insert

Weight: Adding 3 Kg

Max Load: 150 Kg

Article numb.: TS 01 002

Dimensions in mm

